

HT-9237 Digital Pen-Type Thermo-Hygrometer

Specifications

Temperature	0°C to 50°C or 0°F to 122°F
Resolution	0.1°C or 0.1°F
Accuracy	+/- 1°C or +/- 1.8°F
Humidity	20% to 100%RH
Resolution	0.1%RH
Accuracy	+/- 3%RH from 30% to 70%RH, (otherwise +/-5%RH)
Power	1 x 3V CR2032 Button Cell

Features

On/Off
Min Max memory since power on
°C/°F Selection
Soft Touch Rubberised Plastic Housing
Sintered Rotating Sensor Protector

Operation

Power "on" by pressing on/off button
Power "off" by pressing on/off button
Rotate sintered sensor protector to expose the sensors
Press °F/ °C button to select temperature format
Min Max Memory. Press min/max button once to display the maximum recorded values since power on. Press the same button again to display

Warranty

The product is warranted for 12 months from date of purchase. Should you need to return the product to us please include a copy of the invoice as proof of purchase.



**ATP Instrumentation Ltd
Tournament Way
Ivanhoe Industrial Estate
Ashby De La Zouch
Leicestershire
LE65 2UU**

Tel 01530 566800

Fax 01530 560373

Email sales@atp-instruments.co.uk

Web Site www.atp-instrumentation.co.uk

