

Over **20 years**
folding probe expertise

Tough, tried & tested



a new standard in folding probe thermometers

Fast and fearless in the hottest of kitchens

With over 20 years of folding probe thermometer experience behind us, we're over the moon to announce our new Checktemp4 thermometer. On duty, and on hand ready to go whatever the occasion, Checktemp4 is designed to give fast, accurate temperature readings in busy kitchens.

The fully waterproof design features front and back silicone high grip surfaces. These make it easy to hold and ensure it won't slide off greasy or slippery surfaces when put down.

Ready to go at a moments notice

- Motion sensor wake-up means you don't need to open and close the probe to reactivate it when in stand-by mode
- Hanna Cal Check verifies the thermometer is calibrated at 0°C every time it is switched on

Cool as a cucumber

Not just happy in the heat, Checktemp4 is also fast and accurate for checking chilled and frozen foods with an outstanding accuracy of +/-0.2°C





Easy to hold ergonomic shape – stays happy in your hand



Automatic internal calibration verification – so you know it's telling the truth



Six colours in the range for different food types



HANNA

19.9°C

Checktemp 4



Large forward facing LCD display – just where you want it



Motion sensor wake-up – always on duty in standby mode



Waterproof case which floats – easier to rescue and retrieve



Tool free battery compartment

Battery life is an impressive 4000 hours but when you do eventually need to change the battery, it's good to know you won't need to find a screwdriver! Our easy to access battery compartment makes the changeover simple and tool free.



Specification

Range	-50.0°C to +300°C with 0.1°C resolution up to 199.9°C
Accuracy	+/- 0.2°C in the critical food range of -30.0°C to +170°C
Probe	Stainless steel 103 x 3mm with penetration tip
Battery	CR2032 batteries included in price
Auto-off	1 min, 2 min(default), 8min, 60min, or always On
Physical	165 x 45 x 24mm and 85 grams in weight

Hanna Cal Check

Hanna Cal Check guarantees 100% accuracy every time. Activated automatically, Cal Check simulates a temperature of 0.0°C providing peace of mind every time you use your Checktemp4.



Choose the colour for your application



White – General Use
Order code HI-151



Yellow – Cooked Meat
Order code HI-151-3



Red – Raw Meat
Order code HI-151-1



Green – Salad, Fruits
Order code HI-151-4



Blue – Raw Fish
Order code HI-151-2



Brown – Vegetables
Order code HI-151-5



WolfLabs

Pricing on any accessories shown can be found by keying the part number into the search box on our website.

The specifications listed in this brochure are subject to change by the manufacturer and therefore cannot be guaranteed to be correct. If there are aspects of the specification that must be guaranteed, please provide these to our sales team so that details can be confirmed.

www.wolflabs.co.uk

Tel : 01759 301142

Fax : 01759 301143

sales@wolflabs.co.uk

Please contact us if this literature doesn't answer all your questions.